

access



ValueBox Basic. Control of valuables.

The Basic series is based on simplicity and security. All cabinets are equipped with a keypad for entering codes and programming. The green diode above the keypad indicates that the cabinet is active and blinks even faster when it is in service mode. The cabinets are available in various models with 2 to 6 compartments.

All cabinets can be expanded using the expansion series, Expansion, by up to 15 cabinets in any combination. In other words, you can have up to 96 compartments in the same system controlled via the main cabinet's keypad.



View our full range at
www.creone.com

Models for Basic.



7002 B

Value box with 2 storage compartments. Internal dimensions:
1 compartment: 260x400x255 mm



7003 B

Value box with 3 storage compartments. Internal dimensions:
1 compartment: 260x400x255 mm
2 compartments: 260x200x255 mm



7004 B

Value box with 4 storage compartments. Internal dimensions:
2 compartments: 260x200x255 mm



7005 B

Value box with 5 storage compartments. Internal dimensions:
2 compartments: 260x200x255 mm
3 compartments: 260x125x255 mm



7006 B

Value box with 6 storage compartments. Internal dimensions:
3 compartments: 260x125x255 mm



Facts and functions.

Basic

- Keypad for entering codes and programming.
- 500 unique codes per cabinet.
- Expandable by up to 15 cabinets from the Expansion series.
- Simple connection (230V).
- Steel, 1.5 mm.
- Powder coating.

Accessories (B)

- Battery backup.



Flexible systems save money

All ValueBoxes are flexible and can be easily adapted to your needs. Start with storage for a few compartments and then expand in step with the growing need. Basic and System can be expanded to up to 96 compartments connected to a main cabinet.

Expansion

- Can be connected to the B or S series main cabinet in any combination.
- Can be controlled directly using an external card reader.
- Lock, electromagnet 12V.
- Powder coating.
- Steel, 1.5 mm.

Accessories (E)

- Alarm contacts.